

AEG

Colombo Combo



**Corded DECT telephone with
answering machine plus
cordless handset**

Warning

Charge the handset for 24 hours before use.

AEG

I.	Important safety information	7
II.	Product set up.....	8
1.	Where to place your product	8
2.	Cordless handset range.....	8
3.	Signal strength	8
4.	Setting up the telephone base and handset	9
5.	Handset battery low warning	10
6.	Handset battery performance	10
7.	Date and time	10
8.	Mains power failure, telephone base only	11
III.	Your telephone base.....	12
IV.	Your cordless handset	13
V.	Using the Colombo Combo.....	14
1.	Moving up and down in the menu of the Telephone base and Cordless handset.	14
2.	Icons in the display	15
3.	To make a call	15
4.	To make a call by pre-dialling	15
5.	To make a quickdial call	16
6.	Call from the phonebook.....	16
7.	Call from the calls list.....	17
8.	Answer a call	17
9.	Handsfree	17
10.	To adjust the volume	18
11.	Secrecy.....	18
12.	To end a call	18
13.	Keylock, cordless handset.....	19
14.	To switch the cordless handset on/off	19

AEG

VI. Phonebook, telephone base	19
1. To view and dial phonebook entries	19
2. To view an entry during a call	19
3. To add an entry	20
4. To edit an entry	21
5. To change a ringtone	21
6. To copy an entry to the cordless handset	21
7. To copy an entry to a mobile SIM card	22
8. To copy all entries to the cordless handset	22
9. To copy all entries to/from a mobile SIM card	23
10. Quickdial memories	23
11. To make a quickdial call	23
12. To Delete an entry	24
13. To Delete all entries	24
14. Memory status	24
15. Dialling codes	24
VII. Calls lists, telephone base	25
1. To view the calls list	26
2. To dial from the calls list	26
3. To save a number from the calls list to the phonebook	26
4. To Delete a calls list entry	27
5. To Delete the entire calls list	27
VIII. Clock & alarm, telephone base	27
1. Set the date and time manually	27
2. Set the alarm	28
3. Alarm on/off	28
4. Time format	28
5. Switch off alarm ring	28

AEG

IX. Settings, telephone base.....	28
1. Ringtone	28
2. Ringer volume.....	29
3. Dialling mode	29
4. Ring priority.....	29
5. Recall mode.....	30
6. System PIN.....	30
7. Master reset.....	30
8. ECO Mode	31
X. Options, telephone base	31
1. Display language	31
2. Screensaver.....	31
3. Light timeout	31
4. Key beep.....	32
5. PABX access code	32
XI. Phonebook, cordless handset.....	32
1. To view and dial phonebook entries	32
2. To view an entry during a call	33
3. To add an entry.....	33
4. To edit an entry.....	34
5. To change a ringtone.....	34
6. To copy an entry to the telephone base	34
7. To copy an entry to a mobile SIM card.....	35
8. To copy all entries to the telephone base	35
9. To copy all entries to/from a mobile SIM card	36
10. Quickdial memories	36
11. To make a quickdial call	36
12. Send a text message to a phonebook entry	37
13. To Delete an entry	37
14. To Delete all entries.....	37
15. Memory status	38

AEG

XII. Using text messaging.....	38
1. Cost of the fixed line Text Messaging service	38
2. Send a text message	39
3. Standard text entry	39
4. Receiving and reading text messages.....	39
5. Read a new message	40
6. Read, reply, forward, delete, call and save numbers when texts are in the Inbox	40
7. Edit or send texts in the Drafts box	41
8. Forward or Delete texts in the Outbox	41
9. Edit templates	41
10. Deleting texts	42
11. Service centre numbers	42
- Add or change Service Centre numbers	42
- Set send centre	42
12. Message alert tone	43
13. Set message size	43
14. PIN protected text message areas	43
- To set up a PIN protected text message area	43
- Send a text message from a PIN protected text message area	44
- How to send a text message to a PIN protected text message area	44
XIII. Calls list, cordless handset.....	44
1. To view the calls list.....	45
2. To dial from the calls list	45
3. To save a number from the calls list to the phonebook	45
4. Send a text message to a calls list number	46
5. To Delete a calls list entry.....	46
6. To Delete the entire calls list.....	46

AEG

XIV. Agenda, cordless handset	47
1. Add a new event	47
2. Switch off agenda ring	48
3. Show agenda details	48
4. Edit agenda.....	48
5. Send agenda as a text message	48
6. Delete Agenda	49
7. Delete all Agendas.....	49
XV. Clock/alarm, cordless handset.....	49
1. Set the date and time manually	49
2. Set the alarm	50
3. Alarm on/off	50
4. Time format.....	50
5. Switch off alarm ring	50
XVI. Settings, cordless handset	50
1. Handset ringtone	50
2. Handset ringer volume.....	51
3. Receiver volume	51
4. Handset name	51
5. Display language	51
6. Screensaver.....	52
7. Light timeout	52
8. Auto talk.....	52
9. Key beep.....	52
10. PBX access code.....	53
11. Dialling mode	53
12. Ring priority.....	53
13. Recall mode.....	54
14. System PIN.....	54
15. Master reset.....	54
16. ECO Mode	55

AEG

XVII. Registration	55
1. To register a handset.....	55
2. To select a base	56
3. To De-register a handset	56
4. Internal Calls	57
5. Transfer a call	57
6. 3-Way conference call	57
XVIII. Answering machine	58
1. To switch the answering machine on/off.....	58
2. Answer Delay	59
3. Time saver	59
4. Switch message alert tone on/off.....	59
5. On-screen alert	60
6. Outgoing messages (OGM).....	60
7. Record your own outgoing message	60
8. Check or delete your outgoing message	61
9. Select outgoing message mode	61
10. Record a memo	62
11. Call screening.....	62
12. Message playback.....	63
13. Cordless handset, button shortcuts	63
14. Delete all old messages.....	63
15. Remote access	64
- Switch remote access PIN On or Off.....	64
- Change the remote access PIN.....	64
- Switch your answering machine on remotely	65
- Play messages remotely	65
16. Memory full	66
XIX. Simple solutions	66
XX. General information	69
XXI. Technical information.....	71

AEG

I. Important safety information

Your Colombo Combo product should be treated with care. The information below has been provided in the interest of safety and will help you to enjoy this product and the benefits it brings for many years.

- . Keep the product and all its parts out of reach of small children.
- . Keep it dry. Avoid exposure to precipitation, humidity and liquids which could all affect the product circuitry.
- . Do not leave it in high temperatures as electronic devices and plastic parts may warp in heat.
- . Do not leave it in low temperatures as moisture can form inside the products, which may damage the circuit boards.
- . Do not store in dusty or dirty areas.
- . Do not use harsh chemicals, cleaning solvents or detergents to clean the product. Wipe with a damp (not wet) soft cloth to clean.
- . Do not attempt to open the product. Unauthorised handling of the device may damage it and will void your warranty.
- . Only use the telephone line cord and power supplies that came with the product. Using an unauthorised power supply will invalidate your guarantee and may irrecoverably damage the telephones.
- . Never dispose of batteries in a fire. There is a serious risk of explosion and/or the release of highly toxic chemicals.
- . Radio signals transmitted between the handset and base may cause interference to hearing aids.

Do NOT use your phone/s near emergency/intensive care medical equipment; if you have a pacemaker fitted or during an electrical storm.

II. Product set up

1. Where to place your product

It is important that you consider carefully in advance where your Colombo Combo telephone and cordless handset will be situated and make sure that they are:



- on a flat and stable surface
- within 1.8 metres of a power socket and telephone socket
- at least 1 metre away from other electrical appliances to avoid any interference
- away from bright sunlight or heat sources, such as a radiator
- not in a humid or very damp place such as a bathroom

Note: Your Colombo Combo product works by sending radio signals between the telephone base and the cordless handset. The strength of the signal depends on where you site the telephone base. Putting it as high as possible ensures the best signal.

2. Cordless handset range

The cordless handset has a range of 300 metres outdoors when there is a clear line of sight between the telephone base and the handset. Any obstruction between the handset and the telephone base will reduce the range significantly. With the telephone base indoors and the handset either indoors or outdoors, the range will normally be up to 50 metres. Thick stone walls can severely affect the range.

3. Signal strength

The  icon on your cordless handset indicates when you are in range. When out of range of the telephone base, « **Searching...** » is displayed and the  icon will flash.

If you move out of range during a call, the telephone call will be disconnected. Move back within range before you make any further calls from the cordless handset. The cordless handset will automatically re-connect to the telephone base.

AEG

IMPORTANT

Only use the mains power adaptors and telephone line cord supplied with the product.

4. Setting up the telephone base and handset

- Telephone base

1. Plug the handset, mains power adaptor (the power adaptor for the telephone base has a small clear plastic plug at one end) and telephone cable into the clearly marked sockets on the underside of the telephone base.
2. Push the metal stand into the two holes underneath the two rubber feet at the back of the product. Make sure the metal stand is pushed firmly into place.
3. Plug the power adaptor into the mains wall socket and switch the power on.

- Cordless handset

1. Plug the mains power adaptor into the power socket on the underside of the charger (the power adaptor for the charger has a small red plastic plug at one end) and plug the other end into the mains power wall socket and switch on.
2. Remove the battery cover from the back of the handset and insert the 2 x AAA rechargeable batteries supplied. Please note the '+' and '-' markings inside the battery compartment and insert the batteries the correct way around. Slide the battery compartment shut.



WARNING

Never use non-rechargeable batteries. Only use the approved rechargeable batteries supplied. Using unapproved batteries will invalidate your guarantee and may damage the telephone.

3. Place the handset onto the base to charge for at least 24 hours. When the handset is fully charged the battery icon in the top right of the display will indicate this.
4. After 24 hours, plug the telephone line cord from the telephone base into the telephone wall socket.

AEG

5. Handset battery low warning

If the  icon flashes in the display, you will need to recharge the cordless handset before you can use it again. During charging, the  icon in the display will scroll.

6. Handset battery performance

In ideal conditions, fully charged batteries should give about 10 hours talk time or 100 hours standby time on a single charge.

Note that new batteries do not reach full capacity until they have been in normal use for several days.

To keep your batteries in the best condition, leave the handset off of its charger base for a few hours at a time.

Running the batteries right down at least once a week will help them last as long as possible.

The charge capacity of rechargeable batteries will reduce with time as they wear out, giving the handset less talk/standby time. Eventually they will need to be replaced.

The batteries and cordless handset may become warm during charging. This is normal.


7. Date and time

Providing you have subscribed to your network's Caller Display service, the date and time is set automatically on your telephone base and cordless handset every time a call is received.

If you do not subscribe to the Caller Display service or would like to set the correct time and date straight away, you can set the date and time manually.

- Set the date and time manually on the telephone base

Note: When you set the time and date on the telephone base, the cordless handset will automatically be updated to the same time and date.

1. Press the button with the line on it, under « **Menu** » on the display. Press the bottom section of the  button to scroll to « **Clock & Alarm** ». Press « **Select** ». « **Date & Time** » will be displayed, then press « **Select** » again.

AEG

2. Using the keypad, enter the date using the format DD-MM-YY e.g. 04-08-10 for 4th August 2010.
3. Press « **Save** » and enter the time using the 24 hour format HH-MM, e.g. 14-45 for 2.45pm.
4. Press « **Save** » to confirm. You can either wait a few seconds for the display to return to standby or press « **Back** » twice. The time that you entered will now be displayed in the top right of the screen.

Your Colombo Combo product is now ready for use.

8. Mains power failure, telephone base only

If you have a mains power failure, you can still use your telephone base to make and receive telephone calls. The phone will ring when you receive an incoming call in power fail mode but the display will not light up and the caller's details will not be stored in the calls list.

You will not be able to use the other features and functions of the telephone base or the cordless handset until mains power is restored.

Need help?


You may find the answer in 'Simple solutions' at the back of this guide.

Hearing aid?

Please note that the Colombo Combo works by sending radio signals between the base and handset.

These signals may interfere with some hearing aids, causing a humming noise.

III. Your telephone base




1	Display	2	Names/Clear/Back Names to open the phonebook menu in standby Clear incorrect input during text editing Back to return to previous menu
3	Redial/Pause (long press)/ Scroll Up/Volume up	4	Message Play/Pause
5	Memory 2	6	Intercom To make an internal call
7	Recall	8	Mobile SIM card slot (in the side)
9	Answering machine on/off/ Skip forward	10	Phonebook/Scroll Down/ Volume down
11	Hash To change the case when entering letters/editing	12	Microphone

AEG

13	Handsfree	14	Play outgoing message/ Skip backward
15	Memory 3	16	Memory 1
17	Incoming call light/power connected/new message light	18	Menu/Select/Secrecy Use to access and select the options in the menu Secrecy to mute the microphone during calls

IV. Your cordless handset



1	Earpiece	2	Display
3	Names/Clear /Back Names to open the phonebook menu in standby Clear incorrect input during text editing Back to return to previous menu	4	Redial/Pause/Scroll Up/ Volume up

AEG

5	End Call/Exit/ Power on/off (press and hold)	6	Hash/Keypad lock To change the case when entering letters/editing Press and hold to lock the keypad
7	Intercom To make an internal call	8	Recall
9	0 To enter a space	10	Phonebook/Scroll Down/ Volume down
11	Talk/Handsfree	12	Menu/Select/Secrecy Use to access and select the options in the menu Secrecy to mute the microphone during calls


V. Using the Colombo Combo

1. Moving up and down in the menu of the Telephone base and Cordless handset.


Throughout this guide the ▲ and ▼ symbols will be used whenever you need to scroll up or down in the product menu.

Please see the illustration below for where to find the up and down buttons on the Telephone base and Cordless handset.

Telephone base:



Cordless handset:



AEG

2. Icons in the display

You will see the following icons in the display of the telephone base and cordless handset.



Missed Calls

Displayed when you have missed calls and new number(s) in the Calls list.



Text messages

You have new SMS text messages



Answering machine messages

You have new answering machine messages



Answering machine

Displayed when the answering machine is on



Handsfree

Displayed when in handsfree mode



Alarm

An alarm has been set

3. To make a call

Telephone base


Lift the handset and dial the number.

Cordless handset


1. Press .
2. Dial the telephone number.

4. To make a call by pre-dialling

Telephone base

1. Enter the phone number (maximum 32 digits). If you make a mistake press « **Clear** ».
2. Press  to dial the phone number entered. To continue the call via the handset, just lift the handset.

Cordless handset


1. Enter the phone number (maximum 32 digits). If you make a mistake press « **Clear** ».
2. Press  to dial the phone number entered.

AEG


5. To make a quickdial call

Note: You will first need to copy phonebook entries to the Quickdial buttons. See pages 23 and 36.

Telephone base

1. Press the Memory 1, 2 or 3 button. The telephone will switch to Handsfree mode and will dial the number. The name of the person you are calling will be displayed. To continue the call via the handset, just lift the handset.
2. Replace the handset or press the  button to end the call, as appropriate.





Cordless handset

1. Press and hold the digit 1, 2 or 3 on the handset keypad. The number will be dialled and the name of the person you are calling will be displayed.
2. Press  to end the call.





6. Call from the phonebook

Note: You will first need to add new entries to the phonebook. See pages 20 and 33.

Telephone base

1. Press . The first entry in the phonebook is displayed.
2. Scroll up  or down  to the entry you want.
3. Press  to dial the number. To continue the call via the handset, just lift the handset.

Cordless handset

1. Press . The first entry in the phonebook is displayed.
2. Scroll up  or down  to the entry you want.
3. Press  to dial the number.

TIP


Instead of scrolling to browse the phonebook entries, press the numeric key corresponding to the first letter of the entry you wish to locate. For example, pressing 2 will show the entries starting with A. Pressing 2 again will show the entries starting with B, etc...

AEG


7. Call from the calls list

Note: You need to subscribe to your network's Caller Line Identification service to be able to see the caller's number in the calls list.

Telephone base

1. Press « **Menu** », scroll ▼ to « **Calls Lists** » and press « **Select** ».
2. Press ▲ or ▼ to highlight « **Missed** », « **Received** » or « **Dialled** » calls. Press « **Select** ».
3. Scroll ▲ or ▼ to the entry you want.
4. Press  to dial the number. To continue the call via the handset, just lift the handset.

Cordless handset


1. Press « **Menu** », scroll ▼ to « **Calls Lists** » and press « **Select** ».
2. Press ▲ or ▼ to highlight « **Missed** », « **Received** » or « **Dialled** » calls. Press « **Select** ».
3. Scroll ▲ or ▼ to the entry you want.
4. Press  to dial the number.

8. Answer a call

Telephone base



When the phone rings, lift the handset to answer the call.

Cordless handset

When the phone rings, press  to answer the call. When answering the handset from the charger base with 'Auto Talk' set to On (see page 52), nothing needs to be pressed.



9. Handsfree

Telephone base

When the phone rings, press the  button to answer the call in Handsfree mode. To continue the call via the handset, just pick up the handset. To switch back to handsfree mode again, just press the  button and replace the handset.

AEG

Cordless handset



When the phone rings, press  twice to answer the call in Handsfree mode. You can press  each time you wish to switch between handset and handsfree mode.

WARNING, Cordless handset

When the phone is ringing, avoid holding the earpiece too close to your ear as it may damage your hearing. Handsfree activation can suddenly increase the volume in the earpiece to a very high level. Make sure the handset is not too close to your ear.

10. To adjust the volume

Telephone base and Cordless handset

During a call, press  or  to adjust the handset or loudspeaker volume. The level is shown in the display.

11. Secrecy


Telephone base and Cordless handset

Use the secrecy feature when you would like to speak to someone else in the same room as you, without your caller hearing you.


1. During a call, press « **Secrecy** ». « **Secrecy On** » is displayed.
2. Press « **Off** » again to turn the microphone back on and speak to your caller again.

12. To end a call

Telephone base

1. Replace the handset or press the  button, as appropriate.
- After you hang up, the duration of your call is displayed for 5 seconds.

Cordless handset

1. Press .
- After you hang up, the duration of your call is displayed for 5 seconds.

AEG

13. Keylock, cordless handset

To lock the keypad:

1. Press and hold the **#** button. « **Keypad Locked** » is displayed.

To unlock the keypad:

1. Press « **Unlock** », followed by the **#** button. « **Keypad Unlocked** » is displayed.

14. To switch the cordless handset on/off

1. Press and hold the small power button on the top left of the handset, just beneath the black touch panel.
2. Press and hold the small power button again to switch the handset back on.

VI. Phonebook, telephone base

You can store up to 250 entries in your Colombo Combo telephone base phonebook. Each number can be up to 24 digits long and each name can be up to 12 characters long, including any dots or spaces. Entries are stored in alphabetical order.

1. To view and dial phonebook entries

1. Press ▼. Display shows the first entry.
2. Scroll ▲ or ▼ to the entry you want. Or to search alphabetically, press ▼ then press the key with the first letter of the name, e.g. if the name begins with N, press 6 twice. The display shows the first entry beginning with N. If required, press ▲ or ▼ to scroll to the exact entry.
3. Press « **Options** ». « **Show Details** » is highlighted. Press « **Select** ».
4. Press **■** or « **Dial** » to dial the entry displayed. To continue the call via the handset, just lift the handset.

2. To view an entry during a call

1. Press « **Names** » to open the phonebook menu.
2. Enter the first letter of the name you want then scroll ▲ or ▼ if necessary to the exact name.

AEG

3. Press « **Options** », then scroll ▼ to « **Show Details** ». Press « **Select** ».
4. Press « **Back** » 3 times to cancel the Phonebook display and return to the call timer display.

3. To add an entry

1. Press « **Names** ». Scroll ▼ to highlight « **Add Entry** ».
2. Press « **Select** ». « **Enter Name:** » is displayed.
3. Enter a name using the keypad and press « **OK** ».
4. Enter a number. Press « **OK** » to save. Press ▲ or ▼ to select a melody and press « **Select** » to confirm.
5. Press « **Back** » to return to standby.

- Enter a pause

If your Colombo Combo is connected to a switchboard, you may need to enter a pause in a stored number. This gives the switchboard time to find an outside line. A Pause is normally stored after the switchboard access code (e.g. 9)

1. When storing a number, press and hold ▲ until the display shows « **P** ».
- You can then continue storing the phone number.

*Note: You can cancel storing an entry at any time during the process by lifting and replacing the handset or waiting for the display to timeout to standby before you press « **OK** » to save.*

- Entering characters/names

Use the alphanumeric keypad to enter names in the phonebook.

For instance to enter the name Paul:

- P Press **7** once
A Press **2** once
U Press **8** twice
L Press **5** three times

To enter a space press **0**.

Press « **Clear** » to « **Delete** » a character.

AEG

4. To edit an entry

1. Press ▼.
2. Scroll ▲ or ▼ to the entry you want to edit and press « **Options** ». Scroll ▼ to « **Edit Entry** » and press « **Select** ».
3. Edit the name and press « **OK** » to confirm. Press « **Clear** » to delete characters.
4. Press « **OK** » and edit the number.
5. Press « **OK** » to confirm.
6. Press ▲ or ▼ to select a melody and press « **Select** » to confirm.
7. Press « **Back** » twice to return to standby.

5. To change a ringtone

You can change a ringtone assigned to a phonebook entry, quickly and simply.

1. Press ▼.
2. Scroll ▲ or ▼ to the entry with the ringtone you want to change and press « **Options** ». Scroll ▼ to « **Ringtone** » and press « **Select** ».
3. Press ▲ or ▼ to select a different melody and press « **Select** » to confirm.
4. Press « **Back** » twice to return to standby.

6. To copy an entry to the cordless handset


1. Press ▼.
2. Scroll ▲ or ▼ to the entry you want to copy and press « **Options** ». Scroll ▼ to « **Copy Entry** » and press « **Select** ». « **To Handset** » is highlighted. Press « **Select** ».
3. The other handsets registered to the telephone base are displayed, e.g. Handset 1. Press ▲ or ▼ to select the handset that you would like to copy the entry to and press « **Select** » to confirm. « **Please wait...** » is displayed.
4. On the receiving handset, e.g. Handset 1, « **Copy Phonebook?** » is displayed. Press « **Yes** » to accept or « **No** » to reject the phonebook entry.
5. Press « **Back** » three times to return to standby.

AEG

7. To copy an entry to a mobile SIM card

*Note: Most mobile SIM card formats are supported by your Colombo product but if your SIM card is not compatible the following message will be displayed « **SIM Format Not Supported** ».*

1. Insert the mobile SIM card into the slot on the right hand side of the telephone base until it clicks into place. Please make sure that you insert the SIM card with the cut corner edge first and with the contacts facing downwards. Please see the following illustration.



2. Press ▼.
3. Scroll ▲ or ▼ to the entry you want to copy and press « **Options** ». Scroll ▼ to « **Copy Entry** » and press « **Select** ». Scroll ▼ to « **To SIM** » and press « **Select** ».
4. « **Please wait...** » is displayed whilst the entry is copied.

*Note: If the SIM card is PIN protected you will be prompted to enter the PIN and then press « **OK** » before the entry can be copied.*

5. Press « **Back** » three times to return to standby.

8. To copy all entries to the cordless handset

1. Press « **Names** ».
2. Scroll ▼ to « **Copy Phonebook** » and press « **Select** ». « **To Handset** » is highlighted. Press « **Select** ».
3. The other handsets registered to the base are displayed, e.g. Handset 1. Press ▲ or ▼ to select the handset that you would like to copy the entries to and press « **Select** » to confirm. « **Please wait...** » is displayed.
4. On the receiving handset, e.g. Handset 1, « **Copy Phonebook?** » is displayed. Press « **Yes** » to accept or « **No** » to reject the phonebook entries.
5. Press « **Back** » three times to return to standby.

AEG

9. To copy all entries to/from a mobile SIM card.

*Note: Most mobile SIM card formats are supported by your Colombo product but if your SIM card is not compatible the following message will be displayed « **SIM Format Not Supported** ».*

1. Insert the mobile SIM card into the slot on the right hand side of the telephone base until it clicks into place. Please make sure that you insert the SIM card with the cut corner edge first and with the contacts facing downwards. Please see the illustration on page 22.
2. Press « **Names** ».
3. Scroll ▼ to « **Copy Phonebook** » and press « **Select** ». Press ▲ or ▼ to scroll to « **From SIM** » or « **To SIM** » and press « **Select** ».
4. « **Please wait...** » is displayed whilst the entries are copied, followed by confirmation of the number of entries that have been copied.

*Note: If the SIM card is PIN protected you will be prompted to enter the PIN and then press « **OK** » before the entries can be copied.*


5. Press « **Back** » four times to return to standby.

10. Quickdial memories

You can copy the 3 phonebook entries that you are likely to call most often, to the 3 1-touch quickdial buttons.

1. Press ▼.
2. Scroll ▲ or ▼ to the entry you want to copy and press « **Options** ». Scroll ▼ to « **Quickdial** » and press « **Select** ».
3. Press ▲ or ▼ to select Memory key 1, 2 or 3 and press « **Select** ».
4. Press ▲ or ▼ to select « **Assign** » or « **Clear Entry** » and press « **Select** ».
5. Press « **Back** » to return to standby.

11. To make a quickdial call

1. Press the Memory key 1, 2 or 3 button. The telephone will switch to Handsfree mode and will dial the number. The name of the person you are calling will be displayed. To continue the call via the handset, just lift the handset.
2. Replace the handset or press the  button to end the call, as appropriate.

AEG

12. To Delete an entry

1. Press ▼.
2. Scroll to the entry you want to « **Delete** » and press « **Options** ».
3. Scroll ▼ to « **Delete Entry** » and press « **Select** ».
4. Display shows « **Delete?** » and the name of the entry. Press « **Yes** » to confirm or « **No** » to return to the options.
5. Press « **Back** » to return to standby.

13. To Delete all entries

1. Press « **Names** ».
2. Scroll ▼ to « **Delete Phonebook** » and press « **Select** ».
3. « **Delete All Entries?** » is displayed. Press « **Yes** » to confirm or « **No** » to return to the options.
4. Press « **Back** » to return to standby.

14. Memory status

You can check how many phonebook entries you have saved on your telephone base and how many entries you still have available.

1. Press « **Names** ».
2. Scroll ▼ to « **Memory Status** » and press « **Select** ». The following information will be displayed, this is an example if only 4 phonebook entries have been saved:

Memory Used: 4

Memory Free: 246

3. Press « **Back** » twice to return to standby.

15. Dialling codes

The dialling codes in your telephone base are preset for the UK as 00 for International, 44 for Country and 0 for Local. These are used when you copy numbers from a mobile SIM card to the Colombo Combo phonebook.

With these settings any mobile number copied which begins with + will be correctly saved as 00 for International, 0 for Country (if the mobile number was UK +44) and 0 for Local or National calls.

AEG

You can change the dialling codes in your telephone base should you need to.

1. Press « **Names** ».
2. Scroll ▼ to « **Dialling Codes** » and press « **Select** ».
3. Press ▲ or ▼ to select « **International** », « **Country** » or « **Local** » and press « **Select** ».
4. Enter the new dialling code, you can use « **Clear** » to delete any unwanted digits and press « **Save** ».
5. Press « **Back** » twice to return to standby.

VII. Calls lists, telephone base

If you have subscribed to Caller Line Identification (CLI), and provided the identity of the caller is not withheld, the number of the caller will be displayed on your handset when you receive an incoming call.

*Notes: If the caller's number is stored in your phonebook along with a name, the name will also be displayed. If the telephone number is not available for incoming calls, « **Unavailable** » will be displayed.*

Information about incoming calls will vary by country and network operator. Some operators may charge a subscription for their Caller Line Identification service.

The calls list contains details of missed, received and dialled calls. Details include the date and time of the call. Entries are displayed in chronological order with the most recent call at the top of the list.

When the calls list is full, a new call replaces the oldest in the list.

The telephone base can hold details of up to 30 answered or unanswered calls and 20 dialled Calls.

If you receive more than one call from the same number, only the most recent call is kept in the calls list.



When you have missed calls (incoming calls that you haven't answered) the display shows « **You have X New missed calls** ». If you press « **Back** », the screen returns to standby and the missed call icon is displayed.

AEG

1. To view the calls list

1. When you see « **You have X New missed calls** » displayed, press « **View** ». You can now scroll ▲ or ▼ through the « **Missed Calls** » list.
Alternatively, if you pressed « **Back** » and the screen is at Standby: Press « **Menu** », press ▲ or ▼ to scroll to « **Calls Lists** » and press « **Select** ». « **Missed Calls** » will be highlighted, press « **Select** » to view the calls list.
2. Press ▲ or ▼ to scroll to the entry you want to view. Press « **Options** », « **Show Details** » is highlighted. Press « **Select** » to see the details.
3. Press « **Back** » five times to return to standby.

2. To dial from the calls list

1. Press « **Menu** », scroll ▼ to « **Calls Lists** » and press « **Select** », « **Missed Calls** » is highlighted. Scroll ▲ or ▼ to choose « **Missed Calls** », « **Received Calls** » or « **Dialled Calls** ».
2. Press « **Select** ». You can now scroll ▲ or ▼ through the list.
3. Press « **Options** », « **Show Details** » is highlighted. Press « **Select** » to see the Caller's details.
4. Press « **Dial** » or  to dial the entry displayed. To continue the call via the handset, just lift the handset.
5. To end the call, replace the handset or press the  button, as appropriate.

3. To save a number from the calls list to the phonebook

1. Press « **Menu** », scroll ▼ to « **Calls Lists** », then press « **Select** », « **Missed Calls** » is highlighted. If required, scroll ▲ or ▼ to « **Received Calls** » or « **Dialled Calls** » then press « **Select** ».
2. Scroll ▲ or ▼ to the entry you want and press « **Options** ».
3. Scroll ▼ to « **Save number** » and press « **Select** ».
4. Enter a name and then press « **OK** ». The number is displayed. Press « **OK** ».
5. Scroll ▲ or ▼ to the ringtone you want and press « **Select** ».
6. Press « **Back** » four times to return to standby.

AEG

4. To Delete a calls list entry

1. Press « **Menu** », scroll ▼ to « **Calls Lists** » and then press « **Select** ». « **Missed Calls** » is highlighted. If required, scroll ▲ or ▼ to « **Received Calls** » or « **Dialled Calls** » then press « **Select** ».
2. Scroll ▲ or ▼ to the entry you want and press « **Options** ».
3. Scroll ▲ to « **Delete Call** ». Press « **Select** ».
4. Press « **Back** » three times to return to standby.

5. To Delete the entire calls list

1. Press « **Menu** », scroll ▼ to « **Calls Lists** » and then press « **Select** ». « **Missed Calls** » is highlighted. Scroll ▼ to « **Delete Calls** » and press « **Select** ».
2. « **Missed Calls** » is highlighted. Scroll ▼ to « **All Calls** » and press « **Select** ».
3. Display shows « **Delete All Calls?** ». Press « **Yes** » to confirm or « **No** » to cancel.
4. Press « **Back** » three times to return to standby.

VIII. Clock & alarm, telephone base

If you subscribe to your network's Caller Identification service, the time on your Telephone base is set automatically each time you receive a call, depending on your network provider.

You can also set or adjust the time using the Clock & Alarm menu.

1. Set the date and time manually

Note: When you set the time and date on the telephone base, the cordless handset will automatically be updated to the same time and date.

1. Press « **Menu** » and scroll ▼ to « **Clock & Alarm** » and press « **Select** ». « **Date & Time** » is highlighted, press « **Select** ».
2. Using the keypad, enter the date using the format DD-MM-YY e.g. 04-08-10 for 4th August 2010.
3. Press « **Save** » and enter the time using the 24 hour format HH-MM, e.g. 14-45 for 2.45pm.
4. Press « **Save** » to confirm. Press « **Back** » twice to return to standby.

AEG

2. Set the alarm

1. Press « **Menu** » and scroll ▼ to « **Clock & Alarm** » and press « **Select** ».
2. Scroll ▼ to « **Alarm** » and press « **Select** ».
3. Press ▲ or ▼ to select « **On** » and press « **Select** ».
4. Press ▲ or ▼ to select « **Once** », « **Mon-Fri** » or « **On Daily** » and press « **Select** ».
5. Enter the time for the alarm to sound and press « **Save** ».
6. Press « **Back** » twice to return to standby.

3. Alarm on/off

1. Press « **Menu** » and scroll ▼ to « **Clock & Alarm** » and press « **Select** ».
2. Scroll ▼ to « **Alarm** » and press « **Select** ».
3. Press ▲ or ▼ to select « **On** » or « **Off** » and press « **Select** ».
4. Press « **Back** » twice to return to standby.

4. Time format

Set the time format to 12 or 24 hour setting.

1. Press « **Menu** » and scroll ▼ to « **Clock & Alarm** » and press « **Select** ».
2. Scroll ▼ to « **Time Format** » and press « **Select** ».
3. Press ▲ or ▼ to select « **12 Hour** » or « **24 Hour** » and press « **Select** ».
4. Press « **Back** » twice to return to standby.

5. Switch off alarm ring

When the alarm sounds, press « **Stop** ».

IX. Settings, telephone base

1. Ringtone

1. Press « **Menu** », scroll ▼ to « **Settings** » and press « **Select** ».
2. « **Ringtone** » is highlighted. Press « **Select** ».
3. Press ▲ or ▼ to highlight « **External Call** » or « **Internal Calls** ». Press « **Select** » to confirm.

AEG

4. Scroll ▲ or ▼ to highlight the ringtone you want, there are 20 to choose from. Press « **Select** » to confirm.
5. Press « **Back** » twice to return to standby.

2. Ringer volume

1. Press « **Menu** », scroll ▼ to « **Settings** » and press « **Select** ».
2. Scroll ▼ to « **Ringer Volume** » and press « **Select** ».
3. Press ▲ or ▼ to highlight the volume level you want, there are 5 to choose from. Press « **Save** » to confirm.
4. Press « **Back** » twice to return to standby.

3. Dialling mode

Your Colombo Combo product is set to Tone dialling. You should not normally need to change this setting. The dial mode options are Tone or Pulse.

1. Press « **Menu** », scroll ▼ to « **Settings** » and press « **Select** ».
2. Scroll ▼ to « **Dialling Mode** ». Press « **Select** ».
3. Press ▲ or ▼ to highlight « **Pulse** » or « **Tone** ». Press « **Select** » to confirm.
4. Press « **Back** » twice to return to standby.

4. Ring priority

Your Colombo Combo product is set so that when you receive an incoming call the telephone base and the cordless handset will ring at the same time. With 'Ring priority' you can set the cordless handset to ring 2, 4 or 6 times before the telephone base will ring.

1. Press « **Menu** », scroll ▼ to « **Settings** » and press « **Select** ».
2. Scroll ▼ to « **Ring priority** ». Press « **Select** ».
3. Scroll ▼ to « **Select Handset** ». Press « **Select** ». The other handsets registered to the base are displayed, e.g. Handset 1. Press ▲ or ▼ to select the handset that you would like to ring first and press « **Select** ».
4. Press ▲ or ▼ to highlight to 2, 4 or 6 Rings and press « **Select** ».
5. Press « **Back** » twice to return to standby.

*Note: To change back to the original setting of the telephone base and cordless handset ringing at the same time. Select « **All handsets** » at Step 3.*

AEG

5. Recall mode

The default recall time is suitable for your country and network operator and is set at 100 ms (Recall 1).

1. Press « **Menu** », scroll ▼ to « **Settings** » and press « **Select** ».
2. Scroll ▼ to « **Recall Mode** ». Press « **Select** ».
3. Press ▲ or ▼ to highlight « **Recall 1** » (100ms) or « **Recall 2** » (250ms). Press « **Select** » to confirm.
4. Press « **Back** » twice to return to standby.

6. System PIN

The System PIN is used when changing certain settings and for handset/base registration/de-registration. The default setting is 0000 but you can change this to your own personal PIN number with up to 8 digits.

When you enter a PIN the digits are displayed as « **** ».

1. Press « **Menu** », scroll ▼ to « **Settings** » and press « **Select** ».
2. Scroll ▼ to « **System PIN** ». Press « **Select** ».
3. Enter the old PIN (original setting 0000) and press « **OK** ».
4. Enter the new PIN and press « **OK** ». Re-enter the new PIN and press « **OK** ».
5. Press « **Back** » twice to return to standby.

7. Master reset

You can restore your product to its default (original) settings. The Phonebook, Calls List and Answering Machine messages and personal Outgoing Messages will not be affected.

All handsets registered to the base will continue to be registered.

All text, answer machine, handset and base settings, such as ringer volumes etc., will be reset.

1. Press « **Menu** », scroll ▼ to « **Settings** » and press « **Select** ».
2. Scroll ▼ to « **Master Reset** ». Press « **Select** ».
3. « **Are You Sure?** » is displayed. Select « **Yes** » to confirm or « **No** » to cancel.
4. If you select « **Yes** », enter the system PIN (original setting 0000) then press « **OK** ». « **Please wait...** » and then « **Reset Complete** » will be displayed. The telephone base will then announce your answering machine outgoing message and then return to standby.

AEG

8. ECO Mode

To reduce the level of power emissions, you can select « **ECO mode** ». When the ECO mode is set to « **On** », the telephone base transmission power will be reduced.

1. Press « **Menu** », scroll ▼ to « **Settings** » and press « **Select** ».
2. Scroll ▼ to « **ECO Mode** ». Press « **Select** ».
3. Press ▲ or ▼ to highlight « **Off** » or « **ECO** ». Press « **Select** » to confirm.
4. Press « **Back** » twice to return to standby.

X. Options, telephone base

1. Display language

Your handset has 5 different display languages, these are **English, French, German, Italian and Spanish**.

Note: As soon as you select a new display language, all the handset text displays will immediately change to this language.

1. Press « **Menu** », scroll ▲ to « **Options** » and press « **Select** ».
2. « **Language** » is highlighted. Press « **Select** ».
3. Scroll ▲ or ▼ to the language you want and press « **Select** ».
4. Press « **Back** » twice to return to standby.

2. Screensaver

1. Press « **Menu** », scroll ▲ to « **Options** » and press « **Select** ».
2. Scroll ▼ to « **Screensaver** » and press « **Select** ».
3. Press ▲ or ▼ to highlight « **Clock** » or « **Off** » and press « **Select** ».
4. Press « **Back** » twice to return to standby.

3. Light timeout

1. Press « **Menu** », scroll ▲ to « **Options** » and press « **Select** ».
2. Scroll ▼ to « **Light Timeout** » and press « **Select** ».
3. Press ▲ or ▼ to highlight « **15 Seconds** », « **30 Seconds** » or « **Off** » and press « **Select** ».
4. Press « **Back** » twice to return to standby.

AEG

4. Key beep

1. Press « **Menu** », scroll ▲ to « **Options** » and press « **Select** ».
2. Scroll ▼ to « **Key Beep** » and press « **Select** ».
3. Scroll ▲ or ▼ to « **On** » or « **Off** ». Press « **Select** » to confirm.
4. Press « **Back** » twice to return to standby.

5. PABX access code



If your Colombo Combo is connected to a switchboard, you may need to enter an access code for an outside line, e.g. 9, before you dial a number. You can save this access code in your telephone base and it will be added automatically each time you dial.

1. Press « **Menu** », scroll ▲ to « **Options** » and press « **Select** ».
2. Scroll ▼ to « **PABX Access Code** » and press « **Select** ».
3. Scroll ▲ or ▼ to « **On** », « **Off** » or « **Set Code** ». Press « **Select** » to confirm.
If you select « **Set code** », enter the switchboard access code e.g. 9, then press « **Save** ».
4. Press « **Back** » twice to return to standby.

XI. Phonebook, cordless handset


The Colombo Combo cordless handset phonebook can store up to 250 names and numbers. Each number can be up to 24 digits long and each name can be up to 12 characters long, including any dots or spaces. Entries are stored in alphabetical order.

1. To view and dial phonebook entries


1. Press ▼. Display shows the first entry.
2. Scroll ▲ or ▼ to the entry you want. Or to search alphabetically, press ▼ then press the key with the first letter of the name, e.g. if the name begins with N, press 6 twice. The display shows the first entry beginning with N. If required, press ▲ or ▼ to scroll to the exact entry.
3. Press « **Options** ». « **Show Details** » is highlighted. Press « **Select** ».
4. Press  or « **Dial** » to dial the entry displayed.
5. Press  to end the call (if dialled), or return to standby.

AEG

2. To view an entry during a call

1. Press « **Names** » to open the phonebook menu.
2. Enter the first letter of the name you want then scroll ▲ or ▼ if necessary to the exact name.
3. Press « **Options** », then scroll ▼ to « **Show Details** ». Press « **Select** ».
4. Press « **Back** » to cancel the Phonebook display.
5. Press  to end the call.

3. To add an entry


1. Press « **Names** ». Scroll ▼ to highlight « **Add Entry** ».
2. Press « **Select** ». « **Enter Name** » is displayed.
3. Enter a name using the keypad and press « **OK** ».
4. Enter a number. Press « **Save** ». Press ▲ or ▼ to select a melody and press « **Select** » to confirm.
5. Press  to return to standby.

- Enter a pause

If your Colombo Combo is connected to a switchboard, you may need to enter a pause in a stored number.

This gives the switchboard time to find an outside line. A Pause is normally stored after the switchboard access code (e.g. 9)

1. When storing a number, press and hold ▲ until the display shows « **P** ».
You can then continue storing the phone number.

Note: You can cancel storing an entry at any time during the process by pressing  to return to standby.

- Entering characters/names

Use the alphanumeric keypad to enter names in the phonebook.

For instance to enter the name Paul:


- P Press **7** once
- A Press **2** once
- U Press **8** twice
- L Press **5** three times

To enter a space press **0**.

Press « **Clear** » to « **Delete** » a character.


AEG

4. To edit an entry


1. Press ▼.
2. Scroll ▲ or ▼ to the entry you want to edit and press « **Options** ». Scroll ▼ to « **Edit Entry** » and press « **Select** ».
3. Edit the name and press « **OK** » to confirm. Press « **Clear** » to delete characters.
4. Press « **OK** » and edit the number.
5. Press « **Save** » to confirm.
6. Press ▲ or ▼ to select a melody and press « **Select** » to confirm.
7. Press  to return to standby.

5. To change a ringtone

You can change a ringtone assigned to a phonebook entry, quickly and simply.

1. Press ▼.
2. Scroll ▲ or ▼ to the entry with the ringtone you want to change and press « **Options** ». Scroll ▼ to « **Ringtone** » and press « **Select** ».
3. Press ▲ or ▼ to select a different melody and press « **Select** » to confirm.
4. Press  to return to standby.

6. To copy an entry to the telephone base


1. Press ▼.
2. Scroll ▲ or ▼ to the entry you want to copy and press « **Options** ». Scroll ▼ to « **Copy Entry** » and press « **Select** ». « **To Handset** » is highlighted. Press « **Select** ».
3. The other handsets registered to the base are displayed as well as the telephone base. Press ▲ or ▼ to scroll to « **Base** » and press « **Select** » to confirm. « **Please wait...** » is displayed.
4. On the telephone base, « **Copy Phonebook?** » is displayed. Press « **Yes** » to accept or « **No** » to reject the phonebook entry.
5. Press  to return to standby.

AEG

7. To copy an entry to a mobile SIM card


*Note: Most mobile SIM card formats are supported by your Colombo product but if your SIM card is not compatible the following message will be displayed « **SIM Format Not Supported** ».*

1. Insert the mobile SIM card into the slot on the right hand side of the telephone base until it clicks into place. Please make sure that you insert the SIM card with the cut corner edge first and with the contacts facing downwards. Please see the following illustration.




2. Press ▼.
3. Scroll ▲ or ▼ to the entry you want to copy and press « **Options** ». Scroll ▼ to « **Copy Entry** » and press « **Select** ». Scroll ▼ to « **To SIM** » and press « **Select** ».
4. « **Please wait...** » is displayed whilst the entry is copied.

*Note: If the SIM card is PIN protected you will be prompted to enter the PIN and then press « **OK** » before the entry can be copied.*

5. Press  to return to standby.

8. To copy all entries to the telephone base

1. Press « **Names** ».
2. Scroll ▼ to « **Copy Phonebook** » and press « **Select** ». « **To Handset** » is highlighted. Press « **Select** ».
3. The other handsets registered to the base are displayed as well as the telephone base. Press ▲ or ▼ to scroll to « **Base** » and press « **Select** » to confirm. « **Please wait...** » is displayed.
4. On the telephone base, « **Copy Phonebook?** » is displayed. Press « **Yes** » to accept or « **No** » to reject the phonebook entries.
5. Press  to return to standby.


AEG

9. To copy all entries to/from a mobile SIM card

*Note: Most mobile SIM card formats are supported by your Colombo product but if your SIM card is not compatible the following message will be displayed « **SIM Format Not Supported** ».*


1. Insert the mobile SIM card into the slot on the right hand side of the telephone base until it clicks into place. Please make sure that you insert the SIM card with the cut corner edge first and with the contacts facing downwards. Please see the illustration on page 35.
2. Press « **Names** ».
3. Scroll ▼ to « **Copy Phonebook** » and press « **Select** ». Press ▲ or ▼ to scroll to « **From SIM** » or « **To SIM** » and press « **Select** ».
4. « **Please wait...** » is displayed whilst the entries are copied, followed by confirmation of the number of entries that have been copied.

*Note: If the SIM card is PIN protected you will be prompted to enter the PIN and then press « **OK** » before the entries can be copied.*


5. Press  to return to standby.

10. Quickdial memories

You can copy the 3 phonebook entries that you are likely to call most often to quickdial locations 1, 2 and 3 on the keypad.

1. Press ▼.
2. Scroll ▲ or ▼ to the entry you want to copy and press « **Options** ».
Scroll ▼ to « **Quickdial** » and press « **Select** ».
3. Scroll ▲ or ▼ to select « **Memory key 1, 2 or 3** » and press « **Select** ».
4. Scroll ▲ or ▼ to select « **Assign** » or « **Clear Entry** » and press « **Select** ».
5. Press  to return to standby.

11. To make a quickdial call

1. Press and hold the digit 1, 2 or 3 on the handset keypad. The number will be dialled and the name of the person you are calling will be displayed.
2. Press  to end the call.

AEG


12. Send a text message to a phonebook entry

1. Press ▼.
2. Scroll ▲ or ▼ to the entry you want to send the message to and press « **Options** ».
3. Scroll ▼ to « **Send Message** » and press « **Select** ».
4. Write the message then press « **Options** ».
5. « **Send** » is highlighted. Then press « **Select** ». (You can also save, insert a symbol, emoticon or template).
6. The number is pre-entered on the « **Send to** » screen, press « **Send** » to send the message.


IMPORTANT

You must subscribe to your Network Provider's Caller Display service so that you can use text messaging and you must not withhold your telephone number.

13. To Delete an entry

1. Press ▼.
2. Scroll to the entry you want to delete and press « **Options** ».
3. Scroll ▼ to « **Delete Entry** » and press « **Select** ».
4. Display shows « **Delete?** » and the name of the entry. Press « **Yes** » to confirm or « **No** » to return to the options.
5. Press  to return to standby.

14. To Delete all entries

1. Press « **Names** ».
2. Scroll ▼ to « **Delete Phonebook** » and press « **Select** ».
3. « **Delete All Entries?** » is displayed. Press « **Yes** » to confirm or « **No** » to return to the options.
4. Press  to return to standby.

AEG


15. Memory status

You can check how many phonebook entries you have saved on your handset and how many entries you still have available.

1. Press « **Names** ».
2. Scroll ▼ to « **Memory Status** » and press « **Select** ». The following information will be displayed, this is an example if only 3 phonebook entries have been saved:

Memory Used: 3

Memory Free: 247

3. Press  to return to standby.

XII. Using text messaging

Your Colombo Combo cordless handset can send and receive text messages from participating mobile networks and compatible landline telephones in Syria, Jordan and Lebanon.

Your handset can store up to a total of 50 short messages across all handset Outbox, Draft and Inboxes.

*Note: If the text mailboxes are full when you attempt to write a new message the display shows « **Memory Full Delete Messages** » for 2 seconds. You must delete messages before you can write and send a new one.*

IMPORTANT

You must subscribe to your Network Provider's Caller Display service so that you can use Text Messaging and you must not withhold your telephone number.

A quarterly fee may be payable, please contact your telephone network provider for more details.

You may also send messages to landline phones that are NOT text compatible. Messages to non-compatible lines will be connected to voice text and delivered in spoken words.

1. Cost of the fixed line Text Messaging service

There is no subscription charge (other than the subscription to Caller Display).

AEG

2. Send a text message

1. Press « **Menu** », « **Text Messaging** » is displayed, press « **Select** ».
2. « **Write Message** » is highlighted. Press « **Select** ».
3. Use the keypad to enter your message.
The maximum number of characters in a text message is 160.
Press **#** to switch between upper case ABC, lower case abc letters and digits.
4. Press « **Options** ». « **Send** » is highlighted.
Press « **Select** » to send the message. Enter the phone number or press « **Search** » to open the phonebook, then scroll to the number you want and press « **Select** ». Now press « **Send** ».

You can also scroll ▲ or ▼ to:

« **SAVE** »

Press « **Select** » to save the message in the Drafts folder.

« **INSERT SYMBOL** »

Press « **Select** ». The symbol table is displayed. Press ▲ or ▼ to highlight the symbol you want and then press « **Insert** ».

« **INSERT EMOTICON** »

Press « **Select** ». The Emoticon table is displayed. Press ▲ or ▼ to highlight the Emoticon you want then press « **Insert** ».

« **INSERT TEMPLATE** »

Press « **Select** ». The list of Templates is displayed. Press ▲ or ▼ to highlight the Template you want then press « **Insert** ».

5. When Sending a message, « **Sending Message** » will be displayed, followed by « **Message Sent** ».

3. Standard text entry


With standard text entry you can enter a word by pressing each letter button a number of times to display the character you want, for example: to write the word « **Hello** », press **4** twice, **3** twice, **5** three times, **5** three times and **6** three times.

4. Receiving and reading text messages

When you receive a new text message, an icon is displayed on the telephone base and the cordless handset as well as « **You have X new message/s** » on the display.

AEG

5. Read a new message

1. Press « **Read** » on the cordless handset, the inbox is opened and the list of messages is displayed. If you press « **Back** » the message is stored in the Inbox for reading later.
2. In the Inbox, scroll ▲ (to more recent messages), or ▼ (to older messages) through the list of messages.
3. Highlight the message you want to read and press « **Read** » or press « **Back** » to return to the Text Messaging Menu.
4. Press  to return to standby.

Note: If you are writing a text and you receive a call, the text will be lost.

6. Read, reply, forward, delete, call and save numbers when texts are in the Inbox

When you see the new message alert, if you press « **Back** » the message is stored in your Inbox so that you can read it later.

1. Press « **Menu** », « **Text Messaging** » is displayed, press « **Select** ». If you have new messages you will go straight to the Inbox, if not scroll ▼ to Inbox and press « **Select** ».
2. Scroll ▲ or ▼ to the message you want to read and press « **Read** ». Scroll ▲ or ▼ through the message.
3. Press « **Options** » and scroll ▲ or ▼ to:

« **REPLY** »

Press « **Select** », write your reply then press « **Options** » and select « **Send** ».

« **FORWARD** »

Press « **Select** ». The message is displayed. Press « **Options** », « **Send** » is highlighted. Press « **Select** » and enter a number or search for the number and then press « **Send** ».

« **MESSAGE DETAILS** »

You can see who sent the message and then call them. Press « **Select** », the sender's number is displayed. Press « **Dial** » if you want to call the number.

AEG

« USE NUMBER »

To call the sender, press « **Select** ». « **Call** » will be displayed. Press « **Select** » to call the sender OR to save the number, scroll ▼ to « **Save** » and press « **Select** ». Enter a name and press « **OK** », edit the number if required then press « **Save** ». Scroll ▲ or ▼ to the ringtone and press « **Select** ». The number is saved in the phonebook.


« DELETE »

Press « **Select** ». Press « **Yes** » to confirm or « **No** » to cancel.


7. Edit or send texts in the Drafts box

1. To open the Drafts box, press « **Menu** », « **Text Messaging** » is displayed. Press « **Select** ».
2. Scroll ▼ to « **Drafts** » and press « **Select** ».
3. Press « **Edit** » to edit your message content.
4. Press « **Options** » and scroll ▲ or ▼ to « **Send** », « **Save** », « **Insert Symbol** », « **Insert Emoticon** », « **Insert Template** » or « **Message Type** ».

8. Forward or Delete texts in the Outbox


1. To open the Outbox, press « **Menu** », « **Text Messaging** » is displayed. Press « **Select** ».
2. Scroll ▼ to « **Outbox** » and press « **Select** ».
3. Scroll ▲ or ▼ to the message you want and press « **Read** ». Scroll ▲ or ▼ through the message.
4. Press « **Options** » and scroll ▲ or ▼ to « **Forward** » or « **Delete** ».
5. Press  to return to standby.

9. Edit templates

1. Press « **Menu** », « **Text Messaging** » is displayed. Press « **Select** ».
2. Scroll ▼ to « **Templates** » and press « **Select** ».
3. Scroll ▲ or ▼ to the template you want to edit and press « **Options** ». Scroll ▲ or ▼ to « **Edit** » and press « **Select** ».
4. Press ▲ or ▼ to scroll through the template, together with the keypad and « **Clear** » to edit the template. Press « **Save** ».
5. Press  to return to standby.

AEG


10. Deleting texts

1. To open the Drafts box, press « **Menu** », « **Text Messaging** » is displayed. Press « **Select** ».
2. Scroll ▼ to « **Delete Messages** » and press « **Select** ».
3. Scroll ▲ or ▼ to « **Inbox** », « **Drafts** », « **Outbox** » or « **All Messages** » and press « **Select** ».
4. Press « **Yes** » to confirm or « **No** » to cancel.
5. Press  to return to standby.


11. Service centre numbers

To send and receive text messages you need the telephone number of your Network's text centre, these are already stored in your handset but if you accidentally delete the Outgoing or Incoming Service Centre numbers, you will need to re-enter them in order for your text service to work. You can enter up to 4 Service Centre numbers - two incoming and two outgoing.

- Add or change Service Centre numbers


1. Press « **Menu** », « **Text Messaging** » is displayed. Press « **Select** ». Scroll ▲ or ▼ to « **Text Settings** » and press « **Select** ».
2. « **Service Centres** » is highlighted, press « **Select** ».
3. Scroll ▲ or ▼ to « **Receive Centres** » or « **Send Centres** » and press « **Select** ».
4. Scroll ▲ or ▼ « **Centre 1** » or « **Centre 2** » and press « **Select** ».
5. Enter the number for the centre and press « **Save** ».
6. Press  to return to standby.

- Set send centre

1. Press « **Menu** », « **Text Messaging** » is displayed. Press « **Select** ». Scroll ▲ or ▼ to « **Text Settings** » and press « **Select** ».
2. « **Service Centres** » is highlighted, press « **Select** ».
3. Press « **Select** » again to choose « **Set Send Centre** ».
4. Scroll ▲ or ▼ to « **Send Centre 1** » or « **Send Centre 2** » and press « **Select** ».
5. Press  to return to standby.

AEG

12. Message alert tone

1. Press « **Menu** », « **Text Messaging** » is displayed. Press « **Select** ». Scroll ▲ or ▼ to « **Text Settings** » and press « **Select** ».
2. Scroll ▼ to « **Message Alert** » and press « **Select** ».
3. Scroll ▲ or ▼ to « **On** » or « **Off** » and press « **Select** ».
4. Press  to return to standby.

13. Set message size

1. Press « **Menu** », « **Text Messaging** » is displayed. Press « **Select** ». Scroll ▲ or ▼ to « **Text Settings** » and press « **Select** ».
2. Scroll ▼ to « **Message Size** » and press « **Select** ».
3. Scroll ▲ or ▼ to highlight « **160** » or « **612** » characters, then press « **Select** ».

Note: A standard text message is 160 characters long. You can set a message to be up to 612 characters and the message will be sent as up to 4 linked messages, each up to 160 characters long.

14. PIN protected text message areas

Your Colombo Combo has been preset so that all text messages are available to every user, but you can set up 4 PIN protected text message areas so that text messages can be kept private.

Each of the 4 PIN protected text message areas has its own Inbox, Outbox and Drafts folder.

Note: Only text messages from landline phones (not mobiles) can be received directly into the PIN protected Inbox but you can send to both landline and mobile phones.

- To set up a PIN protected text message area

1. Press « **Menu** », « **Text Messaging** » is displayed. Press « **Select** ». Scroll ▲ or ▼ to « **Text Settings** » and press « **Select** ».
2. Scroll ▲ to « **Users** » and press « **Select** ».
3. Scroll ▲ or ▼ to highlight user 1, 2, 3 or 4 and press « **Options** ». « **Edit** » is highlighted. Press « **Select** ».
4. Using the keypad, enter the name for the text message area (up to 8 characters), this could be the name of the person who will use it. Press « **Save** ».

AEG

5. The number for this text message area is displayed (1, 2, 3, or 4) it is not recommended that you change this. Press « **Save** ».

6. Using the keypad, enter the 4 digit PIN code for this message area. When you enter each digit it will be displayed as a « * ». Press « **Save** ». Enter the 4 digit PIN code again to confirm it. Press « **Save** ».

The PIN protected text message area has now been set up and will be displayed underneath the 'General' text message area when you select « **Text Messaging** ».

- **Send a text message from a PIN protected text message area**

1. Press « **Menu** », « **Text Messaging** » is displayed, press « **Select** ».

2. « **General User** » is highlighted. Scroll ▼ to highlight the name of the PIN protected message area and press « **Select** ».

3. Using the keypad, enter the 4 digit PIN code and press « **OK** ». « **Write message** » is highlighted. You can now write, read, delete and send text messages as normal.

- **How to send a text message to a PIN protected text message area**

Note: Only text messages from landline phones (not mobiles) can be received directly into the PIN protected Inbox.

When your caller sends a text, by simply adding the number of your text message area (1, 2, 3 or 4), as confirmed at step 5 on page 44, the text will automatically be stored in your PIN protected mailbox.

XIII. Calls list, cordless handset

If you have subscribed to Caller Line Identification (CLI), and provided the identity of the caller is not withheld, the number of the caller will be displayed on your handset when you receive an incoming call.

*Note: If the caller's number is stored in your phonebook along with a name, the name will also be displayed. If the telephone number is not available for incoming calls, « **Unavailable** » will be displayed.*

Information about incoming calls will vary by country and network operator. Some operators may charge a subscription for their Caller Line Identification service.

The calls list contains details of missed, received and dialled calls. Details include the date and time of the call. Entries are displayed in chronological order with the most recent call at the top of the list.

AEG


When the calls list is full, a new call replaces the oldest in the list.

The handset can hold details of up to 30 answered or unanswered calls and 20 dialled Calls.


If you receive more than one call from the same number, only the most recent call is kept in the calls list.

When you have missed calls (incoming calls that you haven't answered) the display shows « **You have X New missed calls** ». If 'Mood lighting' is switched on, this will also flash on the base. If you press « **Back** », the screen returns to standby and the missed call icon is displayed.

1. To view the calls list

1. When you see « **You have X New missed calls** » displayed, press « **View** ». You can now scroll ▲ or ▼ through the « **Missed Calls** » list.
Alternatively, if you pressed « **Back** » and the screen is at Standby: Press « **Menu** », press ▲ or ▼ to scroll to « **Calls Lists** » and press « **Select** ». « **Missed Calls** » will be highlighted, press « **Select** » to view the calls list.
2. Press « **Options** », « **Show Details** » is highlighted. Press « **Select** » to see the details.
3. Press  to return to standby.


2. To dial from the calls list

1. Press « **Menu** », scroll ▼ to « **Calls Lists** » and press « **Select** », « **Missed Calls** » is highlighted. Scroll ▲ or ▼ to choose « **Missed Calls** », « **Received Calls** » or « **Dialled Calls** ».
2. Press « **Select** ». You can now scroll ▲ or ▼ through the list.
3. Press « **Options** », « **Show Details** » is highlighted. Press « **Select** » to see the Caller's details.
4. Press « **Dial** » to call the number.
5. Press  to return to standby.

3. To save a number from the calls list to the phonebook

1. Press « **Menu** », scroll ▼ to « **Calls Lists** », then press « **Select** », « **Missed Calls** » is highlighted. If required, scroll ▲ or ▼ to « **Received Calls** » or « **Dialled Calls** » then press « **Select** ».
2. Scroll ▲ or ▼ to the entry you want and press « **Options** ».

AEG

3. Scroll ▼ to « **Save number** » and press « **Select** ».
4. Enter a name and then press « **OK** ». The number is displayed. Press « **Save** ».
5. Scroll ▲ or ▼ to the ringtone you want and press « **Select** ».
6. Press  to return to standby.


4. Send a text message to a calls list number

1. Press « **Menu** », scroll ▼ to « **Calls Lists** », then press « **Select** », « **Missed Calls** » is highlighted. If required, scroll ▲ or ▼ to « **Received Calls** » or « **Dialled Calls** » then press « **Select** ».
2. Scroll ▲ or ▼ to the entry you want and press « **Options** ».
3. Scroll ▼ to « **Send Message** » and press « **Select** ».
4. Write the message then press « **Options** ».
5. « **Send** » is highlighted. Then press « **Select** ». (You can also save, insert a symbol, emoticon or template).
6. The number is pre-entered on the « **Send to** » screen, press « **Send** » to send the message.

IMPORTANT

You must subscribe to your Network Provider's Caller Display service so that you can use text messaging and you must not withhold your telephone number.


5. To Delete a calls list entry

1. Press « **Menu** », scroll ▼ to « **Calls Lists** » and then press « **Select** ». « **Missed Calls** » is highlighted. If required, scroll ▲ or ▼ to « **Received Calls** » or « **Dialled Calls** » then press « **Select** ».
2. Scroll ▲ or ▼ to the entry you want and press « **Options** ».
3. Scroll ▲ to « **Delete Call** ». Press « **Select** ».
4. Press  to return to standby.

6. To Delete the entire calls list

1. Press « **Menu** », scroll ▼ to « **Calls Lists** » and then press « **Select** ». « **Missed Calls** » is highlighted. Scroll ▼ to « **Delete Calls** » and press « **Select** ».


AEG

2. « **Missed Calls** » is highlighted. Scroll ▼ to « **All Calls** » and press « **Select** ».
3. Display shows « **Delete All Calls?** » Press « **Yes** » to confirm or « **No** » to cancel.
4. Press  to return to standby.


XIV. Agenda, cordless handset

You can use your cordless handset to remind you of details of up to five events such as birthdays, anniversaries or appointments. Each entry can be up to 24 characters long.

1. Add a new event

1. Press « **Menu** », scroll ▼ to « **Agenda** » and press « **Select** ».
2. If no previous event is stored, « **Add Event** », is highlighted, press « **Select** ».
Or
If events are already stored, they are listed. Press « **Options** », « **Add Event** » is highlighted. Press « **Select** ».
3. Enter the subject and press « **Save** ».
4. Enter the date (DD/MM) and press « **Save** ».
5. Enter the time, (HH:MM) and press « **Save** ». If the current time format setting is 12 hour, select « **am** » or « **pm** » by pressing ▲ or ▼.
6. Press ▲ or ▼ to highlight « **Silent** » or « **Alarm** » and press « **Select** ».
7. Press  to return to standby.

If you select alarm:

1. Scroll ▲ or ▼ to highlight « **Once** » or « **Annually** » and press « **Select** ».
2. Scroll ▲ or ▼ to highlight when you want to receive the reminder « **At Event Time** » or « **30 Min Before** », press « **Select** ».
3. Press  to return to standby.

Notes: If you select a silent reminder, the event subject is displayed on the screen but no alarm will sound.


*When the event memory is full, the display shows « **Memory Full** ». You must delete an event before you can add a new one.*

AEG


2. Switch off agenda ring

The event is displayed. Press « **View** » to stop the alarm and see the details of the event. Or press « **Back** » to stop the alarm and return to the standby screen. If no button is pressed, the alarm stops after one minute.


3. Show agenda details

1. Press « **Menu** », scroll ▼ to « **Agenda** » and press « **Select** ».
2. Stored events are displayed. If required scroll ▼ to the event you want and press « **Options** ».
3. Scroll ▼ to « **Show Details** » and press « **Select** ». The description, date and time of the reminder are displayed.
4. Press  to return to standby.

4. Edit agenda

1. Press « **Menu** », scroll ▼ to « **Agenda** » and press « **Select** ».
2. Stored events are displayed. If required scroll ▼ to the event you want and press « **Options** ».
3. Scroll ▼ to « **Edit Event** » and press « **Select** ».
4. Edit the subject and press « **Save** ».
5. Edit the date and time and press « **Save** ».
6. Press ▲ or ▼ to highlight « **Silent** » or « **Alarm** » and press « **Select** ».
7. Press  to return to standby.

If you select alarm:


1. Scroll ▲ or ▼ to highlight « **Once** » or « **Annually** » and press « **Select** ».
2. Scroll ▲ or ▼ to highlight when you want to receive the reminder « **At Event Time** » or « **30 Min before** », press « **Select** ».
3. Press  to return to standby.

5. Send agenda as a text message


1. Press « **Menu** », scroll ▼ to « **Agenda** » and press « **Select** ».
2. Stored events are displayed. If required scroll ▼ to the event you want and press « **Options** ».
3. Scroll ▼ to « **Send as a Text** » and press « **Select** ».
4. The event is displayed. Press « **Options** » to select send option and enter a destination number.
5. Press « **Send** » to send your message.

AEG

6. Delete Agenda

1. Press « **Menu** », scroll ▼ to « **Agenda** » and press « **Select** ».
2. Stored events are displayed. Scroll ▼ to the event you want to delete and press « **Options** ».
3. Scroll ▼ to « **Delete Event** » and press « **Select** ».
4. Press « **Yes** » to confirm or « **No** » to cancel.
5. Press  to return to standby.

7. Delete all Agendas

1. Press « **Menu** », scroll ▼ to « **Agenda** » and press « **Select** ».
2. Stored events are displayed. Press « **Options** ».
3. Scroll ▼ to « **Delete all events** » and press « **Select** ».
4. Press « **Yes** » to confirm or « **No** » to cancel.
5. Press  to return to standby.


XV. Clock/alarm, cordless handset

If you subscribe to your network's Caller Identification service, the time on your handset is set automatically each time you receive a call, depending on your network provider.

You can also set or adjust the time using the Clock & Alarm menu.


1. Set the date and time manually

Note: When you set the time and date on the cordless handset, the telephone base will automatically be updated to the same time and date.


1. Press « **Menu** » and scroll ▼ to « **Clock & Alarm** » and press « **Select** ». « **Date & Time** » is highlighted, press « **Select** ».
2. Using the keypad, enter the date using the format DD-MM-YY e.g. 04-08-10 for 4th August 2010.
3. Press « **Save** » and enter the time using the 24 hour format HH-MM, e.g. 14-45 for 2.45pm.
4. Press « **Save** » to confirm. Press  to return to standby.

AEG

2. Set the alarm


1. Press « **Menu** » and scroll ▼ to « **Clock & Alarm** » and press « **Select** ».
2. Scroll ▼ to « **Alarm** » and press « **Select** ».
3. Press ▲ or ▼ to highlight « **On** » and press « **Select** ».
4. Press ▲ or ▼ to highlight « **Once** », « **Mon-Fri** » or « **On Daily** » and press « **Select** ».
5. Enter the time for the alarm to sound and press « **Save** ».
6. Press  to return to standby.

3. Alarm on/off

1. Press « **Menu** » and scroll ▼ to « **Clock & Alarm** » and press « **Select** ».
2. Scroll ▼ to « **Alarm** » and press « **Select** ».
3. Press ▲ or ▼ to highlight « **On** » or « **Off** » and press « **Select** ».
4. Press  to return to standby.

4. Time format

Set the time format to 12 or 24 hour setting.

1. Press « **Menu** » and scroll ▼ to « **Clock & Alarm** » and press « **Select** ».
2. Scroll ▼ to « **Time Format** » and press « **Select** ».
3. Press ▲ or ▼ to highlight « **12 Hour** » or « **24 Hour** » and press « **Select** ».
4. Press  to return to standby.

5. Switch off alarm ring


When the alarm sounds, press « **Stop** ».

XVI. Settings, cordless handset


1. Handset ringtone

1. Press « **Menu** », scroll ▼ to « **Settings** » and press « **Select** ».
2. « **Set Handset** » is highlighted. Press « **Select** ».
3. « **Ringtone** » is highlighted. Press « **Select** ».
4. Press ▲ or ▼ to highlight « **External Call** » or « **Internal Calls** ». Press « **Select** » to confirm.


AEG

5. Scroll ▲ or ▼ to highlight the ringtone you want, there are 20 to choose from. Press « **Select** » to confirm.
6. Press  to return to standby.

2. Handset ringer volume


1. Press « **Menu** », scroll ▼ to « **Settings** » and press « **Select** ».
2. « **Set Handset** » is highlighted. Press « **Select** ».
3. Scroll ▼ to « **Ringer Volume** » and press « **Select** ».
4. Press ▲ or ▼ to display the volume level you want. Press « **Save** » to confirm.
5. Press  to return to standby.

3. Receiver volume

1. Press « **Menu** », scroll ▼ to « **Settings** » and press « **Select** ».
2. « **Set Handset** » is highlighted. Press « **Select** ».
3. Scroll ▼ to « **Receiver Volume** » and press « **Select** ».
4. Press ▲ or ▼ to display the volume level you want. Press « **Save** » to confirm.
5. Press  to return to standby.

4. Handset name

Personalize your handset, with a name or location for example Peter or Bedroom. Maximum 10 characters.

1. Press « **Menu** », scroll ▼ to « **Settings** » and press « **Select** ».
2. « **Set Handset** » is highlighted. Press « **Select** ».
3. Scroll ▼ to « **Handset Name** » and press « **Select** ».
4. Press « **Clear** » to delete the current name and use the keypad to enter the new handset name. Press « **Save** » to confirm.
5. Press  to return to standby.


5. Display language

Your handset has 5 different display languages, these are English, French, German, Italian and Spanish.


Note: As soon as you select a new display language, all the handset text displays will immediately change to this language.

1. Press « **Menu** », scroll ▼ to « **Settings** » and press « **Select** ».
2. « **Set Handset** » is highlighted. Press « **Select** ».


AEG

3. Scroll ▼ to « **Language** » and press « **Select** ».
4. Scroll ▲ or ▼ to the language you want and press « **Select** ».
5. Press  to return to standby.

6. Screensaver


1. Press « **Menu** », scroll ▼ to « **Settings** » and press « **Select** ».
2. « **Set Handset** » is highlighted. Press « **Select** ».
3. Scroll ▼ to « **Screensaver** » and press « **Select** ».
4. Press ▲ or ▼ to highlight « **Clock** » or « **Off** » and press « **Select** ».
5. Press  to return to standby.

7. Light timeout


1. Press « **Menu** », scroll ▼ to « **Settings** » and press « **Select** ».
2. « **Set Handset** » is highlighted. Press « **Select** ».
3. Scroll ▼ to « **Light Timeout** » and press « **Select** ».
4. Press ▲ or ▼ to highlight 15, 30 or 45 Seconds and press « **Select** ».
5. Press  to return to standby.

8. Auto talk

With Auto talk switched on, you can answer a call just by lifting the handset off of the base.

1. Press « **Menu** », scroll ▼ to « **Settings** » and press « **Select** ».
2. « **Set Handset** » is highlighted. Press « **Select** ».
3. Scroll ▼ to « **Auto Talk** » and press « **Select** ».
4. Scroll ▲ or ▼ to « **On** » or « **Off** ». Press « **Select** » to confirm.
5. Press  to return to standby.


9. Key beep

1. Press « **Menu** » scroll ▼ to « **Settings** » and press « **Select** ».
2. « **Set Handset** » is highlighted. Press « **Select** ».
3. Scroll ▼ to « **Key Beep** » and press « **Select** ».
4. Scroll ▲ or ▼ to « **On** » or « **Off** ». Press « **Select** » to confirm.
5. Press  to return to standby.

AEG

10. PBX access code


If your Colombo Combo is connected to a switchboard, you may need to enter an access code for an outside line, e.g. 9, before you dial a number. You can save this access code in your handset and it will be added automatically each time you dial.

1. Press « **Menu** », scroll ▼ to « **Settings** » and press « **Select** ».
2. « **Set Handset** » is highlighted. Press « **Select** ».
3. Scroll ▼ to « **PBX Access Code** » and press « **Select** ».
4. Scroll ▲ or ▼ to « **On** », « **Off** » or « **Set Code** ». Press « **Select** » to confirm.
If you select « **Set code** », enter the switchboard access code e.g. 9, then press « **Save** ».
5. Press  to return to standby.

You can change some of the settings on the telephone base from the cordless handset.

11. Dialling mode

Your Colombo Combo product is set to Tone dialling. You should not normally need to change this setting. The dial mode options are Tone or Pulse.

1. Press « **Menu** », scroll ▼ to « **Settings** » and press « **Select** ».
2. Scroll ▼ to « **Set Base** ». Press « **Select** ».
3. « **Dialling Mode** » is highlighted. Press « **Select** ».
4. Press ▲ or ▼ to highlight « **Pulse** » or « **Tone** ». Press « **Select** » to confirm.
5. Press  to return to standby.


12. Ring priority

Your Colombo Combo product is set so that when you receive an incoming call the telephone base and the cordless handset will ring at the same time. With 'Ring priority' you can set the cordless handset to ring 2, 4 or 6 times before the telephone base will ring.

1. Press « **Menu** », scroll ▼ to « **Settings** » and press « **Select** ».
2. Scroll ▼ to « **Set Base** ». Press « **Select** ».
3. Scroll ▼ to « **Ring priority** ». Press « **Select** ».
4. Scroll ▼ to « **Select Handset** ». Press « **Select** ». The other handsets registered to the base are displayed, e.g. Handset 1. Press ▲ or ▼ to select the handset that you would like to ring first and press « **Select** ».

AEG

5. Press ▲ or ▼ to highlight to 2, 4 or 6 Rings and press « **Select** ».

6. Press  to return to standby.

*Note: To change back to the original setting of the telephone base and cordless handset ringing at the same time. Select « **All handsets** » at Step 4.*

13. Recall mode


The default recall time is suitable for your country and network operator and is set at 100 ms (Recall 1).

1. Press « **Menu** », scroll ▼ to « **Settings** » and press « **Select** ».

2. Scroll ▼ to « **Set Base** ». Press « **Select** ».

3. Scroll ▼ to « **Recall Mode** ». Press « **Select** ».

4. Press ▲ or ▼ to highlight « **Recall 1** » (100ms) or « **Recall 2** » (250ms). Press « **Select** » to confirm.

5. Press  to return to standby.

14. System PIN

The System PIN is used when changing certain settings and for handset/base registration/de-registration. The default setting is 0000 but you can change this to your own personal PIN number with up to 8 digits.

When you enter a PIN the digits are displayed as « **** ».


1. Press « **Menu** », scroll ▼ to « **Settings** » and press « **Select** ».

2. Scroll ▼ to « **Set Base** ». Press « **Select** ».

3. Scroll ▼ to « **System PIN** ». Press « **Select** ».

4. Enter the old PIN (original setting 0000) and press « **OK** ».

5. Enter the new PIN and press « **OK** ». Re-enter the new PIN and press « **OK** ».

6. Press  to return to standby.

15. Master reset

You can restore your product to its default (original) settings. The Phonebook, Calls List and Answering Machine messages and personal Outgoing Messages will not be affected.

All handsets registered to the base will continue to be registered.


All text, answer machine, handset and base settings, such as ringer volumes etc., will be reset.

AEG

1. Press « **Menu** », scroll ▼ to « **Settings** » and press « **Select** ».
2. Scroll ▼ to « **Set Base** ». Press « **Select** ».
3. Scroll ▼ to « **Master Reset** ». Press « **Select** ».
4. « **Are You Sure?** » is displayed. Select « **Yes** » to confirm or « **No** » to cancel.
5. If you select « **Yes** », enter the system PIN (original setting 0000) then press « **OK** ». « **Please wait...** » and then « **Reset Complete** » will be displayed. The handset will return to standby.

16. ECO Mode

To reduce the level of power emissions, you can select « **ECO mode** ». When the ECO mode is set to « **On** », the base transmission power will be reduced.

1. Press « **Menu** », scroll ▼ to « **Settings** » and press « **Select** ».
2. Scroll ▼ to « **Set Base** ». Press « **Select** ».
3. Scroll ▼ to « **ECO Mode** ». Press « **Select** ».
4. Press ▲ or ▼ to highlight « **Off** » or « **ECO** ». Press « **Select** » to confirm.
5. Press  to return to standby.

XVII. Registration

Up to 5 handsets can be registered to the Colombo Combo base. Additional handsets must be fully charged and registered to the base before you can use them.

Note: The cordless handset in the box with the Colombo Combo telephone base will already have been registered and you will not need to register it.

- The instructions described below apply specifically to a Colombo Combo cordless handset. If you wish to register another manufacturer's handset, the instructions may vary. In this case, please refer to the manufacturer of the additional handset.
- The Master PIN is required before you can register or de-register handsets. The default PIN is 0000.

1. To register a handset

At the telephone base:

1. Press and hold the **intercom** button for at least 3 seconds until you hear a double beep. You have 60 seconds in which to register your additional handset.

AEG

At the handset:

2. If the handset is new and « **Please Register** » is displayed. Press « **Menu** ». « **Registration** » is displayed, press « **Select** ».

Or

If the handset has already been registered to another base, the standby display is shown. Press « **Menu** », scroll ▲ or ▼ to « **Registration** » and press « **Select** ».

3. « **Register Handset** » is highlighted, press « **Select** ».
4. Bases are displayed. If necessary scroll ▲ or ▼ to a new base you wish to register your handset to and press « **Select** ».
5. Enter the System PIN (original PIN is 0000) and press « **OK** ».
6. « **Searching Base X** » (where X is the chosen base number) then « **Handset Registered** » is displayed.


The handset is automatically assigned the next available handset number e.g.: 2.

2. To select a base

You can register your handset with up to 4 bases. Once registered, you can switch between bases, for example, bases at home and at work.

1. Press « **Menu** », scroll ▲ or ▼ to « **Registration** » and press « **Select** ».
2. Scroll ▼ to « **Select Base** » and press « **Select** ».
3. All base numbers are displayed. « **(In use)** » is added to bases where the handset has been previously registered. Scroll ▲ or ▼ to the base you want and press « **Select** ».
4. « **Searching base...** » is displayed, followed by the standby display for that base.

3. To De-register a handset

1. Press « **Menu** », scroll ▲ or ▼ to « **Registration** » and press « **Select** ».
2. Scroll ▼ to « **De-register** » and press « **Select** ».
3. Enter the system PIN (original PIN is 0000) and press « **OK** ».
4. Scroll ▲ or ▼ to the handset you want to de-register and press « **Select** ».
5. Press « **Yes** » to confirm or « **No** » to cancel. The display confirms de-registration.
6. Press  to return to standby.

AEG

4. Internal Calls

With your Colombo Combo you can make internal calls between the cordless handset and the telephone base.

At the telephone base:

1. Press **intercom** followed by the number of the cordless handset **1**.
2. Press « **OK** » to dial.

At the cordless handset:



1. Press **int** (bottom right of the keypad), followed by the number of the telephone base **0**.
2. Press « **OK** » to dial.

*Note: When an internal call is received, the display shows « **Internal Call Handset 1** » or « **Base** », as appropriate.*

5. Transfer a call

You can transfer an external call from the telephone base to the handset or from the handset to the telephone base.

During your call:

1. Press **Int** on the cordless handset or **Intercom** on the telephone base, followed by the number of the handset **1** or telephone base **0** that you want to call.
2. Press « **OK** » to dial or press « **End** » to cancel the call request and return to the caller.
3. When the other handset answers you can announce the caller.
4. Press  on the cordless handset or replace the handset/press  on the telephone base to complete the transfer.



6. 3-Way conference call

You can hold a 3-way conference call between 2 internal and 1 external caller.

During your call to an external caller:

1. Press **Int** on the cordless handset or **Intercom** on the telephone base, followed by the number of the handset **1** or telephone base **0** that you want to call.
2. Press « **OK** » to dial.


AEG

- When the other handset/telephone base answers you can announce the caller.
- Press « **Join** » to begin the conference call. « **Conference Call** » is displayed.
- Press  on the cordless handset or replace the handset/press  on the telephone base to end the call.


XVIII. Answering machine

Your Colombo Combo answering machine records unanswered calls when it is activated. It can store up to 59 messages within the maximum recording time of 30 minutes. Each message can be up to 3 minutes long. Your personal outgoing messages can be up to 3 minutes long.

On the telephone base you can quickly access the main answering machine functions via the central square button surrounding the green « **Play/Pause** » button. Please see the illustration below:



- To switch the answering machine on/off

Note: When the answering machine is switched on the telephone base and the cordless handset will display  in standby mode.

Telephone base

Press the square surround to the right of the Play/Pause button.

Cordless handset

- Press « **Menu** », scroll ▼ to « **Answer Machine** » and press « **Select** ».
- Scroll ▼ to « **Answer On/Off** » and press « **Select** ».
- Scroll ▲ or ▼ to highlight « **On** » or « **Off** » and press « **Select** ».

AEG


2. Answer Delay

Answer delay sets the number of times your product will ring before the answer machine picks up the call and starts playing the outgoing message. You can change this to between 2-9 rings or Time Saver. The default setting is 5 rings.

Telephone base

1. Press « **Menu** », « **Answer Machine** » is highlighted. Press « **Select** ».
2. Scroll ▲ to « **Answer Settings** » and press « **Select** ».
3. Scroll ▼ to « **Answer Delay** » and press « **Select** ».
4. Scroll ▲ or ▼ to highlight the delay you want. Press « **Select** » to confirm.
5. Press « **Back** » three times to return to standby.

Cordless handset

1. Press « **Menu** », scroll ▼ to « **Answer Machine** » and press « **Select** ».
2. Scroll ▼ to « **Answer Settings** » and press « **Select** ».
3. Scroll ▲ or ▼ to « **Answer Delay** » and press « **Select** ».
4. Scroll ▲ or ▼ to highlight the delay you want. Press « **Select** » to confirm.
5. Press  to return to standby.

3. Time saver

When you ring in to access your messages remotely, if your answering machine 'Answer Delay' is set to time saver, and you have new messages, it will answer after 2 rings. If you do not have any new messages it will answer after 5 rings. This means that you can hang up after 3 rings knowing you have no new messages and saving you the cost of the call.

4. Switch message alert tone on/off

Telephone base

1. Press « **Menu** », « **Answer Machine** » is highlighted. Press « **Select** ».
2. Scroll ▲ to « **Answer Settings** » and press « **Select** ».
3. Scroll ▼ to « **Message Alert** » and press « **Select** ».
4. Scroll ▲ or ▼ to highlight « **On** » or « **Off** » and press « **Select** ».
5. Press « **Back** » three times to return to standby.

Cordless handset

Press « **Menu** » and scroll ▼ to « **Answer Machine** » and press « **Select** ».
Follow as for the telephone base from step 2.

AEG

5. On-screen alert

When you have new answering machine messages, the screen on the telephone base and the cordless handset displays « **You have X new messages** ».

Press « **Play** », then scroll ▲ or ▼ through the list of messages if there is more than one. All new messages are indicated by a dot.

Press « **Play** » to hear the highlighted message.

6. Outgoing messages (OGM)

The outgoing message is the message a caller first hears when the answering machine picks up their call. There are 2 pre-recorded outgoing messages to choose from or you can record your own up to 3 minutes long.

- Answer & Record

The caller can leave a message. The pre-recorded message is "Hello, your call cannot be taken at this moment, so please leave your message after the tone".

- Answer Only

The caller can listen to your announcement but cannot leave a message. The pre-recorded message is "Hello, your call cannot be taken at this moment, and you cannot leave a message, so please call later".

7. Record your own outgoing message

Telephone base

1. Press « **Menu** », « **Answer Machine** » is highlighted. Press « **Select** ».
2. Scroll ▼ to « **Outgoing Message** » and press « **Select** ».
3. « **Record** » is highlighted. Press « **Select** ».
4. Scroll ▲ or ▼ to « **Answer & Record** » or « **Answer Only** » and press « **Select** ».
5. You will hear "Please Speak after the Tone" and this is also displayed on the handset.
6. After the tone, speak your message clearly into the handset then press « **Save** » to end the recording.
7. Your outgoing message is played back. If you want to delete it, press « **Delete** » during playback. If you press « **Save** » or wait for the message to play back, it will be saved.

AEG

Cordless handset

1. Press « **Menu** » and scroll ▼ to « **Answer Machine** » and press « **Select** ».
Follow as for the telephone base from step 2.

8. Check or delete your outgoing message

Deleting a personal outgoing message automatically reinstates the pre-recorded outgoing message. You cannot delete a pre-recorded message.

Telephone base

1. Press « **Menu** », « **Answer Machine** » is highlighted. Press « **Select** ».
2. Scroll ▼ to « **Outgoing Message** » and press « **Select** ».
3. Scroll ▼ to « **Play** » and press « **Select** ».
4. Scroll ▲ or ▼ to « **Answer & Record** » or « **Answer Only** » and press « **Select** ».
5. Scroll ▼ to « **Personal OGM** » and press « **Select** ».
6. The message is played. Press « **OK** » to stop playback or press « **Delete** » to delete a personal OGM.

Cordless handset

1. Press « **Menu** » and scroll ▼ to « **Answer Machine** » and press « **Select** ».
Follow as for the telephone base from step 2.

9. Select outgoing message mode

Telephone base

1. Press « **Menu** », « **Answer Machine** » is highlighted. Press « **Select** ».
2. Scroll ▼ to « **Answer Settings** » and press « **Select** ».
3. « **Answer Mode** » is highlighted. Press « **Select** ».
4. Scroll ▲ or ▼ to « **Answer & Record** » or « **Answer Only** » and press « **Select** ».
5. If there is a personal OGM saved, press ▲ or ▼ to « **Default OGM** » or « **Personal OGM** » and press « **Select** ». Your selection is confirmed. If there is no personal OGM saved the default OGM will be selected.

Cordless handset

1. Press « **Menu** » and scroll ▼ to « **Answer Machine** » and press « **Select** ».
Follow as for the telephone base from step 2.

AEG

10. Record a memo

Telephone base

1. Press « **Menu** », « **Answer Machine** » is highlighted. Press « **Select** ».
2. Scroll ▼ to « **Record Memo** » and press « **Select** ».
3. You will hear "Please Speak after the Tone" and this is also displayed on the handset.
4. After you hear the tone, speak your memo then press « **Save** » to end the recording.
5. Your memo is played back. If you want to delete it, press « **Delete** » during playback. If you press « **Save** » or wait for the message to play back, it will be saved.

Cordless handset

1. Press « **Menu** » and scroll ▼ to « **Answer Machine** » and press « **Select** ». Follow as for the telephone base from step 2.


11. Call screening

When your answering machine is on and answers a call, you can use the loudspeaker to listen to the caller leaving a message. You can then identify the caller and decide whether to take the call in person.

Telephone base

Just pick up the handset to speak to the caller.

Cordless handset

1. When your product rings, wait for the answering machine to take the call. When the caller begins leaving a message, the handset will display « **Recording** ». Press « **Screen** » to hear the caller.
2. To interrupt and speak to the caller, press  or, after the caller has hung up and the display shows « **You have a new message** », press « **Play** » to play new messages.


AEG

12. Message playback

Telephone base

1. Press « **Menu** », « **Answer Machine** » is highlighted. Press « **Select** ».
2. « **Play** » is highlighted. Press « **Select** » and scroll ▲ or ▼ to choose which messages to listen to. Press « **Play** ».
During playback you can « **Pause** », « **Skip Forward** », « **Skip Backward** », or « **Delete** » your messages.

Cordless handset

1. Press « **Menu** » and scroll ▼ to « **Answer Machine** » and press « **Select** ».
2. « **Play** » is highlighted. Press « **Select** » to choose which messages you want to play or scroll ▼ to « **Play All** » and press « **Select** » to play all messages.
3. You can press  to switch between the earpiece and handset loudspeaker to listen to your messages.
During playback press « **Options** », then scroll ▲ or ▼ to: « **Pause** », « **Repeat Message** », « **Skip Forward** », « **Skip Backward** », « **Delete** ».
4. Press « **Select** » to choose the highlighted option.

13. Cordless handset, button shortcuts

During playback:

1	Pause
2	Resume
3	Repeat message
4	Play previous message
5	Delete current message
6	Play next message

14. Delete all old messages

Telephone base

1. Press « **Menu** », « **Answer Machine** » is highlighted. Press « **Select** ».
2. Scroll ▼ to « **Delete Messages** » and press « **Select** ».
3. « **Delete All Old Messages?** » is displayed. Press « **Yes** » to confirm or « **No** » to cancel.

AEG

Cordless handset

1. Press « **Menu** » and scroll ▼ to « **Answer Machine** » and press « **Select** ».
Follow as for the telephone base from step 2.

15. Remote access

You can operate your answering machine from any Touchtone™ phone by calling your Colombo Combo product and entering a 4 digit security code (original code is 0000).

- **Switch remote access PIN On or Off**

Telephone base

1. Press « **Menu** », « **Answer Machine** » is highlighted. Press « **Select** ».
2. Scroll ▼ to « **Answer Settings** » and press « **Select** ».
3. Scroll ▲ or ▼ to « **Remote Access** » and press « **Select** ».
4. Scroll ▲ or ▼ to highlight « **On** » or « **Off** » and press « **Select** ».

Cordless handset

1. Press « **Menu** » and scroll ▼ to « **Answer Machine** » and press « **Select** ».
Follow as for the telephone base from step 2.

- **Change the remote access PIN**

You should change your remote PIN from the original setting of 0000 to something more memorable and personal to you. Please keep a note of your new PIN and keep it somewhere safe.

Telephone base

1. Press « **Menu** », « **Answer Machine** » is highlighted. Press « **Select** ».
2. Scroll ▼ to « **Answer Settings** » and press « **Select** ».
3. Scroll ▲ or ▼ to « **Remote Access** » and press « **Select** ».
4. Scroll ▲ or ▼ to highlight « **Set Remote PIN** » and press « **Select** ».
5. Enter the old 4 digit PIN and press « **Save** » (original PIN is 0000).
6. Enter the new 4 digit PIN and press « **Save** ». Enter the new PIN again and press « **Save** ».

Cordless handset

1. Press « **Menu** » and scroll ▼ to « **Answer Machine** » and press « **Select** ».
Follow as for the telephone base from step 2.

AEG

- Switch your answering machine on remotely

If you forget to switch your answering machine on, you can do it remotely from another phone.

1. Dial your phone number and let it ring. After 20 rings you will hear your outgoing message.
2. Press * on the telephone keypad and then enter your security code (original setting 0000).
3. Press **0** and your answering machine will switch on ready to answer incoming call.

- Play messages remotely

1. Dial your phone number and let it ring. When you hear your outgoing message, press *.
2. Enter your 4 digit PIN.

If you enter an incorrect PIN you will hear "Incorrect security code". You can try and enter the PIN 1 more time. If it is still incorrect you will hear the above voice prompt and the Colombo Combo product will end the call.

3. If no button is pressed for 8 seconds or more your Colombo Combo product will end the call.
4. Use your telephone keypad to operate your answering machine:

1	To hear the main menu
2	Play messages
3	Play new messages
4	Skip back during messages
5	Delete during messages
6	Skip forward during messages
7	Set to answer only (or answer & record) depending upon the Answer Mode status of the product at the time.
8	Record a new outgoing message
9	To set to answer off
0	To set to answer on

AEG

16. Memory full

The memory is full if there is less than 10 seconds of recording time left or if the maximum total of 59 messages has been reached.

When the memory becomes full:

- . Your caller will be advised to complete their message within 10 seconds. If they are still talking when the memory becomes full they will hear "Thank you for calling" and the answering machine will hang up.
- . The machine will automatically switch to Answer Only mode and you will need to delete some messages before any more new messages can be recorded.

XIX. Simple solutions

No dialling tone

- . No power - check the connections. Reset the telephone base: unplug and plug back in the mains power.
- . Batteries are empty - charge the batteries for at least 24 hours. Replace the rechargeable batteries.
- . You are too far from the telephone base - move closer to the base
- . Wrong line cord - only use the telephone line cord provided
- . Micro filter (required if you have Broadband) is not connected inbetween your telephone line cord and the telephone wall socket - connect the micro filter to your telephone line cord.

Poor audio quality

- . The telephone base is too close to electrical appliances, reinforced concrete walls or metal door frames - move the base at least one metre away from any electrical appliances.
- . Micro filter (required if you have Broadband) is not connected inbetween your telephone line cord and the telephone wall socket - connect the micro filter to your telephone line cord.

The handset is not charging when the handset is placed on the charger base

- . Poor charging contact, move the handset slightly on the base.
- . Dirty contacts - Unplug from the mains power and clean the charging contacts with a cloth (Do not get wet, do not immerse in water)

AEG

The signal icon is blinking

- . Handset is not registered to the base - register the handset to the base
- . You are too far from the base - move closer to the base
- . Check that the mains power is connected correctly.
- . The batteries may be low, place the handset in the charger to recharge.

No ring tone

- . The ring tone is switched off.
- . Increase the ringer volume.

Caller Line Identification (CLI) service does not work

- . Check your subscription with your network operator

A phonebook entry cannot be stored

- . The phonebook is full. Delete unused entries.

No display

- . Try recharging or replacing the batteries in the cordless handset
- . Try disconnecting and connecting the telephone base power supply.

Unable to register another handset

- . Maximum number of 5 handsets has been reached.
- . The display shows « **Searching** ». You must de-register a handset in order to register a new one.

Noise interference on your radio or television

- . Your telephone base or charger may be too close. Move it as far away as possible.

You hear busy tone when you press when you try to make a call.

- . Another handset registered to the same base, may be on a call.
- . Make sure that your cordless handset is within range of the base.

Answering machine does not record messages

- . Switch the answering machine on.
- . The memory may be full. If so, you will need to delete some messages.
- . Answer mode may be set to « **Answer Only** ». Change the mode to « **Answer & Record** ».

AEG

Cannot access messages remotely

- Remote access may be switched off.
- Check that you are using the correct PIN code.

Cannot record outgoing message

- The memory may be full. If so, you will need to delete some messages.

Answering machine stops automatically

- The memory may be full. If so, you will need to delete some messages.
- The maximum individual message length is 3 minutes.

Possible problems with text messaging

Text messages cannot be sent and the screen displays « Message Sending Failed »

- The telephone base station power supply or telephone line cord might not be properly connected. Check that the base station power supply is plugged into the mains power socket and switched on and that the telephone is plugged into the telephone wall socket.
- There might be a fault on the line. Check that your telephone is working properly.
- You might have deleted the server number in error. See page 42 for instructions on how to enter this number.

Cannot send texts

- Check the service centre number is correct. In order to send and receive text messages you must not withhold your number.

Cannot receive texts

- More than 1 text message product is connected to the telephone line. Disconnect the other products.
- Check that the service centre number is correct
- Ensure that you have subscribed to a Caller Display service and that it is active. You can check this by noting if your phone displays your Caller's number when you receive an incoming call.

AEG

Your SIM card will not click home into the slot on the telephone base

- . Please make sure that you have inserted the SIM card the correct way around, cut off corner first, with the contacts facing downwards.

You keep hearing an error beep

- . You have pressed the wrong button in a sequence. Check the prompts in the display or refer to instructions in this user guide.

XX. General information

Cleaning

- . Clean the handset and base with a damp (not wet) cloth, or an anti-static wipe.
- . Never use household polish as this will damage the product. Never use a dry cloth as this may cause a static shock.

Environmental

- . Do not expose to direct sunlight.
- . The handset may become warm when the batteries are being charged or during prolonged periods of use. This is normal. However, we recommend that to avoid damage you do not place the product on antique/veneered wood.
- . Do not stand your product on carpets or other surfaces which generate fibres, or place it in locations preventing the free flow of air over its surfaces. Do not submerge any part of your product in water and do not use it in damp or humid conditions, such as bathrooms.
- . Do not expose your product to fire, explosive or other hazardous conditions.
- . There is a slight chance your base and handset could be damaged by an electrical storm. We recommend that you unplug the power and telephone line cord during an electrical storm.

Product disposal instructions



- The symbol shown here and on the product means that the product is classed as Electrical or Electronic Equipment and should not be disposed with other household or commercial waste at the end of its working life.
- The Waste of Electrical and Electronic Equipment (WEEE) Directive (2002/96/EC) has been put in place to recycle products using best available recovery and recycling techniques to minimize the impact on the environment, treat any hazardous substances and avoid increasing landfill.

- Product disposal instructions for residential users

- When you have no further use for it, please remove any batteries and dispose of them and the product per your local authority's recycling processes. For more information please contact your local authority or the retailer where the product was purchased.

How many telephones can I have?

All items of telephone equipment have a Ringer Equivalence Number (REN), which is used to calculate the number of items which may be connected to any one telephone line. Your Colombo Combo product has a REN of 1. A total REN of 4 is allowed. If the total REN of 4 is exceeded, the telephones may not ring. With different telephone types there is no guarantee of ringing, even when the REN is less than 4.

Any additional handsets and chargers that you register have a REN of 0.

R&TTE

This product is intended for use within Syria, Jordan and Lebanon for connection to the public telephone network and compatible switchboards.

This equipment complies with the essential requirements for the Radio Equipment and Telecommunications Terminal Equipment Directive 1999/5/EC.

Connecting to a switchboard

This product is intended for use within Syria, Jordan and Lebanon for connection to the public telephone network and compatible switchboards, which support tone dialling and timed break recall. If in doubt please consult your service provider.

AEG

Inserting a pause

With some switchboards, after dialling the access code you may have to wait for a moment while the switchboard picks up an outside line so you will need to enter a pause in the dialing sequence.

1. Press and hold ▲ until the display shows P to insert a pause before entering the telephone number.

You may also need to enter a pause when storing international numbers or charge card numbers

Recall

You may need to use the recall function if you are connected to a switchboard/PBX (Private Branch Exchange), contact your PBX supplier for further information.

XXI. Technical information

Technical Specification

Standard:	Digital Enhanced Cordless Telecommunications (DECT)
Operating Frequency:	1880-1900 MHz
Range:	300 m outdoors and 50 metres indoors, in ideal conditions
Operating duration:	100 hours standby time 10 hours of talk time
Operating temperature:	0°C to 45°C (32°F to 113°F)
Storage temperature:	-20°C to 60°C (-4°F to 140°F)
Rechargeable batteries (each handset):	2 x NiMH 1.2V (AAA)
Base unit voltage:	100-240V / 50/60Hz

Declaration of Conformance

Hereby, AEG declares that this Colombo Combo product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

AEG



ASISTANCE TECHNIQUE:

assistance@sopeg.fr

Ou

Au numéro suivant:

+ 33 (0)5-45-60-82-51



Service technique: assistance@sopeg.fr

ou

05-45-60-82-51 (prix d'un appel local)